



---

# SERVICE MANUAL

## EV100ZX™ Controller

<b>2FBC15</b>	<b>&amp;</b>	<b>2FBC18</b>	<b>A2BC1-20001-up</b>
<b>2FBC20</b>	<b>&amp;</b>	<b>2FBC25</b>	<b>A2BC2-20001-up</b>
<b>2FBC25E</b>	<b>&amp;</b>	<b>2FBC30</b>	<b>A2BC3-20001-up</b>

## Optional TR3000™ Controller

<b>2FBC15</b>	<b>&amp;</b>	<b>2FBC18</b>	<b>A2BC1-60001-up</b>
<b>2FBC20</b>	<b>&amp;</b>	<b>2FBC25</b>	<b>A2BC2-60001-up</b>
<b>2FBC25E</b>	<b>&amp;</b>	<b>2FBC30</b>	<b>A2BC3-60001-up</b>

**CHASSIS  
MAST**



**Chapter 1: General Information**

Scope .....	1.1
Truck Models Covered .....	1.1
Nameplate and Serial Number Locations .....	1.2
Dimensions .....	1.3
Dimensions Chart .....	1.4
General Information (Standard Models) .....	1.5

**Chapter 2: Front Axle & Reduction Differential**

Description .....	2.1
Front Axle .....	2.1
General Information .....	2.1
Front Wheels .....	2.2
Removal .....	2.2
Method 1 .....	2.3
Method 2 .....	2.3
Method 3 .....	2.3
Installation .....	2.4
Axle Disassembly .....	2.5
Removing Front Wheel Hub .....	2.6
Inspection after Disassembly .....	2.7
Axle Shafts .....	2.7
Reassembly .....	2.8
Axle Housing .....	2.8
Front Wheel Hub .....	2.8
Hub Bearing Preload .....	2.9
Reduction Differential .....	2.10
Description .....	2.10
Disassembly .....	2.11
Removing Bearing Inner Races .....	2.11
Inspection after Disassembly .....	2.12
Reduction Gear .....	2.12
Differential .....	2.12
Reassembly .....	2.13
Inspection and Adjustment .....	2.15
Side Bearing Preload .....	2.15
Reduction Gear Backlash .....	2.15
Reduction Gear Face Runout .....	2.16
Tooth Contact .....	2.16
Tooth Contact Adjustment .....	2.17

# TABLE OF CONTENTS

---

## Chapter 3: Transfer Case

Description.....	3.1
Earlier Version .....	3.1
Later Version .....	3.2
Disassembly .....	3.3
Removal .....	3.3
Reassembly.....	3.4

## Chapter 4: Rear Axle

Description.....	4.1
Rear Axle .....	4.1
Rear Wheels.....	4.2
Removal .....	4.2
Installation .....	4.3
Rear Axle .....	4.5
Removal .....	4.5
Installation .....	4.6
Disassembly .....	4.7
Inspection after Disassembly .....	4.9
Reassembly.....	4.10
Inspection and Adjustment .....	4.15
Minimum Turning Radius Adjustment.....	4.15

## Chapter 5: Brake System

Description.....	5.1
Automatic Adjusting Device .....	5.1
Master Cylinder .....	5.2
Disassembly/Earlier Version.....	5.2
Disassembly/Later Version .....	5.3
Inspection after Disassembly .....	5.5
Reassembly.....	5.5
Service Brakes .....	5.6
Disassembly (2FBC15/18).....	5.6
Disassembly (2FBC20/25/25E/30) .....	5.7
Inspection after Disassembly .....	5.9
Reassembly (2FBC15/18) .....	5.10
Reassembly (2FBC20/25/25E/30).....	5.11
Wheel Cylinders .....	5.14
Disassembly/Earlier Version.....	5.14
Disassembly/Later Version .....	5.15
Inspection after Disassembly .....	5.16
Reassembly.....	5.16
Inspection and Adjustment .....	5.17

**Chapter 6: Steering System**

Description ..... 6.1  
     Steering System with EV100ZX Controller ..... 6.1  
         Oil Flow Sequence ..... 6.1  
         General Information..... 6.1  
     Steering System with Optional TR3000 Controller ..... 6.2  
         Oil Flow Sequence ..... 6.2  
         General Information..... 6.2  
 Steering Gear..... 6.3  
     Removal ..... 6.3  
         Steering Gear with EV100ZX Controller ..... 6.4  
         Steering Gear with Optional TR3000 Controller ..... 6.5  
         Inspection after Removal ..... 6.6  
     Installation ..... 6.6  
     Disassembly..... 6.7  
         Steering Gear with EV100ZX Controller ..... 6.7  
         Steering Gear with Optional TR3000 Controller ..... 6.8  
         Inspection after Disassembly ..... 6.12  
     Reassembly ..... 6.13  
         Truck with EV100ZX Controller..... 6.13  
     Truck with Optional TR3000 Controller..... 6.14  
         Inspection after Reassembly..... 6.19  
 Steer Pump – Trucks with EV100ZX Controller Only ..... 6.20  
     Removal ..... 6.20  
     Installation ..... 6.21  
     Disassembly..... 6.22  
         Inspection after Disassembly ..... 6.25  
     Reassembly ..... 6.26  
         Inspection after Reassembly..... 6.29

**Chapter 7: Hydraulic System**

Description ..... 7.1  
     Schematic for Trucks with EV100ZX Controller..... 7.1  
     Schematic for Trucks with Optional TR3000 Controller ..... 7.2  
     Hydraulic Tank ..... 7.3  
     Hydraulic Pump for Trucks with EV100ZX Controller ..... 7.4  
     Hydraulic Pump for Trucks with Optional TR3000 Controller ..... 7.5  
     Control Valve..... 7.7  
     Lift and Tilt Cylinders ..... 7.8  
     Flow Regulator Valve ..... 7.9  
     Down Safety Valve..... 7.10  
 Removal and Installation General Warning ..... 7.11

# TABLE OF CONTENTS

---

## Chapter 7: Hydraulic System, continued

Hydraulic Pump .....	7.12
Removal .....	7.12
Trucks with EV100ZX Controller.....	7.12
Trucks with Optional TR3000 Controller.....	7.13
Installation .....	7.14
Trucks with EV100ZX Controller.....	7.14
Trucks with Optional TR3000 Controller.....	7.14
Disassembly .....	7.15
Trucks with EV100ZX Controller.....	7.15
Trucks with Optional TR3000 Controller.....	7.16
Inspection after Disassembly .....	7.20
Body.....	7.20
Bushes and Balance Plate.....	7.20
Gears .....	7.20
Priority Valve (Trucks with Optional TR3000 Controller Only) .....	7.29
Disassembly .....	7.29
Reassembly.....	7.32
Control Valve .....	7.35
Removal .....	7.35
Trucks with EV100ZX Controller.....	7.35
Trucks with Optional TR3000 Controller.....	7.36
Installation .....	7.37
Disassembly .....	7.38
Inspection after Reassembly .....	7.40
Reassembly.....	7.40
Lift and Tilt Cylinders .....	7.41
Removal .....	7.41
Lift Cylinders/Earlier Version.....	7.41
Lift Cylinders/Later Version.....	7.43
Installation .....	7.45
Tilt Cylinders/Earlier Version.....	7.46
Tilt Cylinders/Later Version.....	7.47
Disassembly .....	7.49
Lift Cylinders .....	7.49
Tilt Cylinders/Earlier Version.....	7.50
Tilt Cylinders/Later Version.....	7.51
Inspection after Disassembly.....	7.52
Precautions for Reassembly.....	7.52

**Chapter 7: Hydraulic System, continued**

Flow Regulator Valve.....	7.53
Disassembly .....	7.53
Inspection and Adjustment .....	7.54
Hydraulic Tank .....	7.54
Control Valve .....	7.55
Lift and Tilt Cylinders .....	7.57
Adjusting Method.....	7.58
Testing .....	7.59

**Chapter 8: Mast and Forks/Earlier Version**

Description.....	8.1
Components .....	8.1
Removal and Installation .....	8.3
Mast and Lift Bracket Assembly .....	8.3
Disassembly .....	8.6
Inspection after Disassembly.....	8.8
Reassembly .....	8.9
Inspection and Adjustment .....	8.10
Forks.....	8.10
Chain Tension Adjustment.....	8.11
Clearance Adjustment on Lift Bracket .....	8.12
Mast Clearance Adjustment.....	8.14
Main Roller Shim Replacement.....	8.17
Mast Adjustment Chart .....	8.20

**Chapter 9: Mast and Forks/Later Version**

Description.....	9.1
Components .....	9.1
Removal and Installation .....	9.2
Mast and Lift Bracket Assembly .....	9.2
Disassembly .....	9.4
Inspection after Disassembly.....	9.6
Reassembly .....	9.7
Inspection and Adjustment .....	9.8
Forks.....	9.8
Chain Tension Adjustment.....	9.9
Clearance Adjustment on Lift Bracket .....	9.10
Mast Clearance Adjustment.....	9.13
Main Roller Shim Replacement.....	9.15
Mast Strip Adjustment.....	9.15
Tilt Angle Adjustment .....	9.16
Lift Cylinder Stroke Adjustment .....	9.17
Bleeding Lift Cylinders.....	9.17
Service Data .....	9.18
Troubleshooting .....	9.20

# TABLE OF CONTENTS

---

## Chapter 10: Troubleshooting Section

Front Axle and Reduction Differential.....	10.1
Brake System.....	10.2
Steering System.....	10.4
Hydraulic System.....	10.6
Rear Axle.....	10.8
Mast and Forks.....	10.9

## Chapter 11: Maintenance Service Data Section

Maintenance Service Data.....	11.1
Front Axle and Reduction Differential.....	11.1
Transfer Case.....	11.3
Rear Axle.....	11.4
Brake System.....	11.6
Steering System.....	11.11
Hydraulic System.....	11.13
Mast and Forks (Simplex Mast).....	11.18
Tightening Torques for Standard Bolts and Nuts.....	11.23
Fine Thread – With Spring Washer.....	11.23
Fine Thread – Without Spring Washer.....	11.24
Coarse Thread – With Spring Washer.....	11.25
Coarse Thread – Without Spring Washer.....	11.26
Maintenance Chart.....	11.27
Periodic Replacement Parts.....	11.33
Lubrication.....	11.34
Lubrication Chart.....	11.34
Fuel and Lubricant Specifications.....	11.35
Recommended Brands of Lubricants.....	11.36
Weight of Major Components (Approximate).....	11.37
Special Service Tools.....	11.38
Special Tool Illustrations.....	11.39
Inspection Guide.....	11.42